



Max lifting capacity: 75t Max. boom length: 57m Max. fixed jib combination: 45m+18m

The parameters, pictures and standard/optional equipment are only for reference in this brochure, the actual machine is based on the effective price list and contract.





SCC750A-5 SANY CRAWLER CRANE 75 TONS LIFTING CAPACITY

QUALITY CHANGES THE WORLD

Main Characteristics

- Page 04 Product Specification
- Page 07 Safety Device



Product Specification



Engine

- Model: ISUZU 6HK1 Diesel engine;
- Type: 4-stroke, water-cooled, 6 cylinders vertical in-line , direct injection, turbo-charger, intercooler, complied with Chinese Nonroad Tier III Emission Standard;
- Displacement: 7.79L;
- Rated power: 212kW/2000rpm;
- Operation power: 200kW/1800rpm;
- Max. Torque: 1080N·m/1500rpm;
- Starter: 24V-5.0kW;
- Radiator: fin type aluminum plate core;
- Air cleaner: Dry type system with main filter element, safety element and resistance indicator;
- Fan: With silicone oil clutch, saving energy and cutting noise;
- Fuel filter: Replaceable paper element;
- Batteries: Two 12V capacity batteries, connected in series;
- Fuel tank capacity: 400L.

Electrical Control System

- Self-developed SYIC-II integrated control system is adopted with higher integration, precise operation and reliable quality;
- Control system consists of power system, engine system, main control system, LMI system, auxiliary system and safety monitoring system. CAN BUS is used for data communication between controller, monitor and the engine;
- Monitor: the working parameters and status are shown on the monitor, such as the engine speed, fuel volume, engine oil pressure, servo pressure, engine working hours, lifting conditions and boom angle;
- The Sky Eye System and remote control of machine traveling on/ off the trailer is offered as optional.

Hydraulic System

- Main pumps: open variable displacement piston pumps of large displacement are adopted to provide oil supply for main actuators of main machine;
- Gear pump: dual gear pump for swing, radiator and control circuit;
- Control: main pump adopts electrically-controlled positive flow control; winch motor adopts limitless adjustable piston motor of variable displacement. The operating components are two cross hydraulic handle, one dual travel pedal control valve to control various actuators proportionally;
- Way of cooling: heat exchanger, fan core and multi-stage cooling;
- Filter: large flow, high precision filter, with bypass valve and transmitter, which can remind the user to replace the filter element in time;
- Max. pressure of system: 33 Mpa;
- Main/aux. load hoist, luffing and travel system: 33Mpa;
- Swing system: 24 MPa;
- Control system: 4.5 MPa;
- Hydraulic Tank Capacity: 260L.

Main and Aux. Load Hoist Mechanism

- Main and aux. load hoist winches are driven separately by motor via gearbox. Operating winch handle can control the winch to rotate to two directions, which are lifting and lowering of hook. Excellent inching function is equipped on the machine;
- Drums with fold-line grooves can ensure the wire rope reeved in order in multilayers;
- Free fall for main/aux. load hoist are offered as optional.

Main and Aux. Load Hoist Mechanism	Drum diameter	520mm
	Rope speed of main/auxiliary winch	0 ~135m/min
	Wire rope diameter	φ22mm
	Wire rope length of main/ auxiliary load hoist	240m/150m
	Rated single line pull	7.5t



Boom Hoist

- Boom hoist winch is driven separately by motor via gearbox.
 Operating winch handle can control the winch to rotate to two directions, which are lifting and lowering of boom;
- Drums with fold-line grooves can ensure the wire rope reeved in order in multilayers.

Boom hoist	Drum diameter	355mm
	Boom hoist rope speed	0~96m/min
	Wire rope diameter	φ16mm
	Wire rope length of boom hoist	148m

Swing Mechanism

- Swing brake adopts wet, spring loaded, normally-closed brake, and braking through spring force;
- Swing system, equipped with integrated swing buffer valve, has free slipping function. It is featured in steady starting and control, and excellent inching function. Unique swing buffer design and steadier brake;
- Swing drive: internal engaged swing drive with 360° swing range, and the max. swing speed is 2.5r/min. The max. drive pressure can reach 20MPa;
- Swing lock: mechanical lock can ensure the upperworks locked securely after work or during transport;
- Swing ring: single row ball bearing.

Cab and Control

- The upgraded cab is designed with interior and control consoles more softened and consistent. The hatchback glass at front and sliding windows at two sides ventilate the cab and facilitate the communication with outsides. The layout of seat, handles, control buttons are designed with ergonomic principles to make operation more comfortable;
- Monitor: The integrated touch screen and independent monitoring display makes man-machine interaction more perfect;
- Armrest box: on the left and right armrest box are control handles, electrical switches, emergent stop and ignition switch. The armrest box can be adjusted along with the seat;
- Seat: multi-way and multi-level floating adjustable seat with unload switch;
- A/C: cool and heat air; optimized air channels and vents;
- Monitoring cameras with auto-back video, can monitor in real time the conditions behind the counterweight and surrounding around.

Counterweight

- Counterweight trays and blocks are stacked for easier assembly and transport;
- Total rear counterweight: 24.3t (approximately);
- Rear counterweight: counterweight tray 9.5t, 3.8t counterweight block×2, 3.6t counterweight block×2;
- Carbody counterweight: 2t counterweight block×2.

Upperworks

 High-strength steel weld framework, with no torsion or deformation. The parts are laid out in the way that is easier for maintenance and service.

Product Specification



Lowerworks

- Independent travel driving units are adopted for each side of the crawler, to realize straight walking and turning driven by travel motor through gearbox and drive wheel;
- Outrigger cylinders of lowerworks are offered as options.

Crawler Extension and Retraction

The crawlers can extend and retract via cylinders. During Work Mode, the crawlers must be extended, and be retracted during transport with crawlers on.

Crawler Tensioning

• The jack is used to push the guide wheel and insert the shim to adjust crawler tension.

Track Pad

- High-strength alloy cast steel track pad can prolong the service life;
- They are 800mm wide, and the total amount is 65pcs x 2.

Operating Equipment

All chords of boom of operating equipment are high-strength steel tubes, and the boom/jib top sheaves are made of highstrength anti-wearing Nylon material protecting wire rope. The hooks are installed with milled welded steel sheave. Pendant cables with quick hitch connector that are easy to assemble are offered as options.

Boom

- Lattice structure. The chord adopts high-strength structural tube and each section is connected through pins;
- Basic boom: 6m boom top+6m boom base;
- Insert: 3m×1,6m×1,9m×4;
- Boom length: 12m ~57m.

Fixed Jib

- Lattice structure. The chord adopts high-strength structural tube and each section is connected through pins;
- Basic boom: 4.5m boom top +4.5m boom base;
- Insert: 4.5m×2;
- Length of fixed jib: 9m~18m;
- Longest boom+jib: 45m boom+18m jib.

Extension Jib

- The extension jib is a welded structure connected to the boom by pins, used for auxiliary hook;
- Extension jib length: 1.1m.

Hook Block

- 75t hook block, 5 sheaves;
- 45t hook block, 3 sheaves;
- 15t hook, 1 sheave;
- 9t ball hook.

Hook Limitation Height





Hook	L	Hook	Ľ
75t	3.5m	9t	2.8m
45t	3.1m		
15t	2.9m		

06

Main Characteristics

Safety Device



Installation/working mode switching switch

- In Assembly Mode, certain safety devices are disabled to facilitate crane assembly;
- In Work Mode, all safety limiting devices activate to protect the operation.

Emergency Stop

In emergency situation, this button is pressed down to cut off the power supply of the whole machine and all actions stop.

Load Moment Indicator (LMI)

- It is an independent computerized safety control system. LMI can automatically detect the load weight, work radius and boom angle, and present on the display the rated load, actual load, work radius and boom angle. In normal operation, the LMI can make a judgment and cut off automatically if the crane moves towards dangerous direction. It can also perform as a black box to record the lifting information;
- Composition: monitor, angle sensor, force sensor and other parts.

Over-hoist Protection of the Main/Auxiliary Load Hoist

Over-hoist protection device comprises limit switch and weight on boom top, which prevents the hook lifting up too much. When the hook is lifted up to the limit height, the limit switch activates, buzzer on the left control panel sends alarm, failure indicator light starts to flash and the hook hoisting action is cut off automatically.

Over-release Protection Device of the Main/Auxiliary Load Hoist

It is comprised of activator in the drum and proximity switch to prevent over-release of wire rope. When the rope is paid out close to the last three wraps, the proximity switch acts, and the system sends alarm through buzzer and show the alarm on the monitor, automatically cutting off the winch action.

Function Lock

If the function lock lever is not in work position, all the other handles won't work, which prevents any mis-operation caused by accidental collision.

Boom Hoist Drum Lock

Boom hoist lock is designed to lock the drum when the boom doesn't need to move, in order to prevent mis-operation. The boom hoist pawl can open and close by control of handle, and when the handle return to neutral position, the pawl will lock the drum automatically to ensure the work safety of boom.

Slewing Lock

Slewing Lock can lock the upperworks and lowerworks of crane in front, rear, left and right directions.

Boom Limit Device

When the boom elevation angle reaches the upper limit, the buzzer sounds and boom action is cut off. This protection is twostage control ensured by both LMI system and travel switch.

Back-stop Device

Its major components are nesting tubes and spring, in order to buffer the boom backlash and prevent further tipping back.

Boom Angle Indicator

Pendulum angle indicator is fixed on the side of boom base close to the cab, so as to provide convenience to the operator.

Hook Latch

The lifting hook is installed with a baffle plate to prevent wire rope from falling off.

Safety Device



Tri-color Load Indicator

The load indicator light has three colors, i.e., green, yellow and red; and the real time load status is presented on the display. When the actual load is smaller than 90% of rated load, the green light is on; when the actual load is larger than 90% and smaller than 100%, the yellow light is on, the alarm light flashes and sends out intermittent sirens; when the actual load reaches 102% of rated load, the red light is on, the alarm light flashes and sends out continuous sirens. At this moment, the system will automatically cut off the crane's dangerous operation.

Alarm Light

When the machine is powered on, the alarm light will work when time comes, so as to warn people around.

Swing Indicator Light

The slewing indicator light flashes during traveling or slewing.

Illuminating Light

The machine is equipped with short-beam light in front of machine, front angle adjustable far-beam light, lamps in operator's cab, lighting devices for night operation, so as to increase the visibility during work.

Rearview Mirror

It is installed on the left of the operator's cab and at the front handrail of the sheet metal for monitoring the rear part of the machine.

Pharos

Pharos is mounted on the top of boom/jib to indicate the height.

Anemometer

It is mounted on the top of boom/jib, and displayed on the monitor in the cab.

Electronic Level Gauge

It displays the tipping angle of crane on the monitor in real time and sends out alarm to the operator automatically when the angle is out of limit.

Seat Interlock

If the operator leaves the seat, all control handles will be locked immediately to prevent any mis-operation due to accidental collision.

Engine Power Limit Load Adjustment and Stalling Protection

The controller monitors the engine power to prevent engine getting stuck and stalling.

Engine Status Monitoring

The engine status will be presented, such as engine coolant temperature, fuel volume, total work hours, engine oil pressure, engine speed, battery charging and voltage.

Monitoring System

Standard remote monitoring system: It can provide functions like GPS locating, GPRS data transfer, machine status inquiry and statistics, operating data monitoring and analysis, and remote diagnosis of failures.



SCC750A-5 SANY CRAWLER CRANE 75 TONS LIFTING CAPACITY

QUALITY CHANGES THE WORLD

Technical Parameters

- Page 10 Major Performance & Specifications
- Page 11 Outline Dimension
- Page 12 Transport Dimensior
- Page 16 Transport Plan



Major Performance & Specifications

Major Perform	ance & Specifications of SCC750A-5		
Performance India	cators	Unit	Parameter
Boom Configuration	Max. rated lifting capacity	t	75
	Largest lifting moment	t∙m	300
	Boom length	m	12~57
	Main boom luffing angle	0	30~81
	Max. rated lifting capacity	t	7.5
Fixed jib	Jib length	m	9~18
	Longest boom + jib	m	45+18
	Rope speed of main/auxiliary load hoist winch	m/min	0~135
	Rope speed of boom hoist winch (3rd layer)	m/min	0~96
speed	Swing speed	rpm	0~2.5
	Travel speed	km/h	0~1.1
	Main load hoist wire rope: Diameter × length	¢ mm × m	φ 22 × 240
Wire rope	Auxiliary load hoist wire rope: Diameter \times length	∮ mm × m	φ 22 × 150
	Rated single line pull of main/aux. load hoist wire rope	t	7.5
Engine	Model/Displacement	١L	ISUZU 6HK1\7.79
Engine	Rated power/revolution speed	kW/rpm	212/2000
	Weight of machine with basic boom	t	66.9
Transport	Rear counterweight	t	24.3
	Transport weight of basic machine (with crawler frames and boom base)	t	36.5
	Transport weight of basic machine (without crawler frames and boom base)	t	19.2
	Machine transport dimension (with crawler frames and boom base) L x W x H $$	mm	12500 × 3200 × 3450
	Machine transport dimension (without crawler frames and boom base) L x W x H $$	mm	8100 × 3000 × 3150
Other	Average ground pressure (basic boom)	MPa	0.077
specifications	Gradeability	%	30

Outline Dimension





<u>3800</u> 3000

4850/3200 (Extended/Retracted)

1500

980

Transport Dimension













Basic machine 1(with boom, crawler)	×1
Length(L)	12.50m
Width(W)	3.20m
Height(H)	3.45m
Weight	36.5t

Basic machine 2 (with boom base)	×1
Length (L)	12.50m
Width (W)	3.00m
Height (H)	3.15m
Weight	20.5t

Basic machine 3	×1
Length (L)	8.10m
Width (W)	3.00m
Height (H)	3.15m
Weight	19.2t

Crawler	×2
Length(L)	6.10m
Width(W)	1.10m
Height(H)	1.10m
Weight	8.0t

Boom base	×1
Length(L)	6.22m
Width(W)	1.51m
Height(H)	1.87m
Weight	1.24t

Boom top	×1
Length(L)	6.48m
Width(W)	1.51m
Height(H)	1.65m
Weight	1.0t

Transport Dimension













9m boom insert	×4
Length(L)	9.13m
Width(W)	1.51m
Height(H)	1.55m
Weight	0.9t

×1
6.14m
1.51m
1.55m
0.62t

3m boom insert	×1
Length (L)	3.14m
Width (W)	1.51m
Height (H)	1.55m
Weight	0.38t

Fixed jib top	×1
Length(L)	4.87m
Width(W)	0.87m
Height(H)	0.92m
Weight	0.31t

Fixed jib base and strut	×1
Length(L)	4.75m
Width(W)	0.87m
Height(H)	1.18m
Weight	0.75t

4.5m fixed jib insert	×2
Length(L)	4.57m
Width(W)	0.87m
Height(H)	0.83m
Weight	0.24t

13

Transport Dimension













Extension jib	×1
Length (L)	1.40m
Width (W)	1.00m
Height (H)	0.80m
Weight	0.13t

С	counterweight tray	×1
L	ength (L)	3.80m
V	Vidth (W)	1.30m
Н	leight (H)	0.72m
V	Veight	9.5t
W	Veight	9.5t

Left counterweight block I	×1
Length (L)	1.90m
Width (W)	1.30m
Height (H)	0.65m
Weight	3.6t

Left counterweight block II	×1
Length(L)	1.90m
Width(W)	1.30m
Height(H)	0.65m
Weight	3.8t

×1
1.90m
1.30m
0.65m
3.6t

×1
1.90m
1.30m
0.65m
3.8t

Transport Dimension











Note:

- 1 . The transport dimensions of each part in the table are schematic, not proportional to the real parts. The dimensions are designed value without package considered.
- 2). The weight is designed value that the actual manufactured part may deviate a little.

Carbody counterweight block	×2
Length(L)	1.60m
Width(W)	0.88m
Height(H)	0.72m
Weight	2.0t

75T hook	×1
Length(L)	1.75m
Width(W)	0.69m
Height(H)	0.37m
Weight	0.7t

45T hook	×1
Length (L)	1.52m
Width (W)	0.69m
Height (H)	0.37m
Weight	0.48t

15T hook	×1
Length (L)	1.34m
Width (W)	0.60m
Height (H)	0.34m
Weight	0.28t

9T ball hook	×1
Length(L)	0.75m
Width(W)	0.30m
Height(H)	0.30m
Weight	0.19t

Transport Plan





- Carbody counterweight block × 2
- 16.68t



SCC750A-5 SANY CRAWLER CRANE 75 TONS LIFTING CAPACITY

QUALITY CHANGES THE WORLD

Cofigurations

Page 20 H Configuration

Page 23 FJ Configuration



Boom Combination



Configuration	Boom Conbination	Boom Length
Н	Boom	
HCm	Boom + Extension jib (double hooks, load on main hook)	12m~57m
HCa	Boom + Extension jib (double hooks, load on aux. hook)	

Note: The schematics above are reference for loading only.

Combination of Working Conditions

Boom Combination



Configuration	Boom Conbination	Boom Length
FJ	Boom + Fixed Jib (single hook)	
FJm	Boom + Fixed Jib (double hooks, load on main hook)	(24m~45m)+(9m~18m)
FJa	Boom + Fixed Jib (double hooks, load on aux. hook)	

Note: The schematics above are reference for loading only.

H Configuration

12m	
15m	■ B 3m T = 🛱
18m	●────B 6m (T → 🛱
21m	■ B 9m T
24m	B 3m 9m T
27m	●────B 6m 9m T → 🛱
30m	●────────────────────────────────────
33m	≪ <b]]3m] 11="" 9m="" td="" →<=""></b]]3m]>
36m	■ B 6m 9m 9m T
39m	
42m	●─────B 3m 9m 9m 9m T 🚔
45m	≪ <u>B</u> 6m 9m 9m 1 9m T
48m	👡 B 3m 6m 9m 9m 9m T
51m	≪⊂B]]3m 9m 9m 9m 1 → 🛱
54m	≪⊂⊂B 6m 9m 9m 9m 9m T 🛱
57m	C B 3m 6m 9m 9m 9m 9m 9m 17

B	6m boom base
T	6m boom top
3m	3m boom insert
6m	6m boom insert
9m	9m boom insert



Combination of Working Conditions

Working Radius in H Configuration



Load Chart of H Configuration

	Load chart -H																
				Вос	om 12~5	57m, Re	ar count	erweigh	nt 24.3t,	Carboc	ly count	erweigh	t 4t				
BL (m) R(m)	12	15	18	21	24	27	30	33	36	39	42	45	48	51	54	57	BL (m) R(m)
4	75.0	69.4															4
5	60.0	60.0	60.0	57.6													5
6	45.0	45.0	44.9	44.6	44.3	42.9											6
7	35.6	35.6	35.5	35.5	35.4	35.1	34.8	33.8									7
8	29.4	29.3	29.3	29.3	29.2	29.1	28.8	28.6	28.4	27.7	26.4						8
9	25.0	24.9	24.9	24.8	24.8	24.7	24.6	24.4	24.3	24.1	23.6	22.5	22.0				9
10	21.7	21.6	21.6	21.5	21.5	21.4	21.3	21.2	21.1	20.9	20.7	20.6	20.0	19.0	18.6		10
11	19.2	19.1	19.0	19.0	18.9	18.8	18.7	18.7	18.6	18.3	18.2	18.0	17.9	17.6	17.2	16.2	11
12		17.0	17.0	16.9	16.9	16.8	16.7	16.6	16.5	16.3	16.2	16.1	15.9	15.8	15.5	15.2	12
14		14.0	14.0	13.9	13.8	13.7	13.6	13.5	13.5	13.4	13.3	13.0	12.9	12.8	12.6	12.5	14
16			11.8	11.7	11.6	11.5	11.4	11.4	11.3	11.1	11.0	10.9	10.7	10.6	10.5	10.4	16
18				10.1	10.0	9.9	9.8	9.7	9.6	9.5	9.3	9.2	9.1	9.0	8.9	8.7	18
20					8.7	8.6	8.5	8.4	8.4	8.2	8.1	8.0	7.8	7.7	7.6	7.4	20
22					7.7	7.6	7.5	7.4	7.3	7.2	7.1	6.9	6.8	6.7	6.6	6.4	22
24						6.8	6.7	6.6	6.5	6.4	6.3	6.0	5.9	5.8	5.7	5.6	24
26							5.9	5.8	5.7	5.6	5.5	5.4	5.2	5.1	5.0	4.9	26
28								5.2	5.1	5.0	4.9	4.8	4.7	4.6	4.3	4.2	28
30									4.7	4.5	4.3	4.2	4.1	4.0	3.9	3.7	30
32									4.1	4.0	3.9	3.8	3.7	3.6	3.4	3.3	32
34										3.6	3.5	3.4	3.3	3.2	3.1	2.9	34
36											3.2	3.1	3.0	2.9	2.7	2.5	36
38												2.8	2.7	2.5	2.3	2.2	38
40												2.4	2.3	2.2	2.1	2.0	40
44														1.7	1.6	1.5	44
48															1.3	1.1	48

Note:

1 . The rated load in the load chart is calculated complying with $\,$ GB/T 3811.

2). The actual rated capacity is the value after deducting the weight of lifting tools (such as lifting hook and steel ropes round the hooks and the

boom top), from the rated load in the load charts. (3). The rated capacity in the load charts is calculated when the crane is parking on firm and level ground and lifting the load slowly and steadily.

④ . See Operation Manual for load charts of HCm and HCa configurations.
 ⑤ . The load table corresponding to weight reduction is detailed in the manual load table.

Combination of Working Conditions

FJ Configuration





FJ Configuration (Longest boom+ jib: 45m+18m)

a



Working Radius in FJ Configuration



Combination of Working Conditions

Load Chart of FJ Configuration

	Load chart -FJ 1/4												
Boom 24m~45m, Jib 9m~18m, Rear counterweight 24.3t, Carbody counterweight 4t, without main hook													
R(m) BL (m)			2	4					2	27			BL (m) R(m)
Jib length(m)	(9	13	3.5	18			9		3.5	18		Jib length(m)
Boom to jib angle	15°	30°	15°	30°	15°	30°	15°	30°	15°	30°	15°	30°	Boom to jib angle
10	7.5						7.5						10
12	7.5	7.5	7.5				7.5	7.5	7.5				12
14	7.5	7.5	7.5	7.3	7.5		7.5	7.5	7.5		7.5		14
16	7.5	7.5	7.5	6.8	7.5		7.5	7.5	7.5	7.0	7.5		16
18	7.5	7.5	7.5	6.4	6.9	5.0	7.5	7.5	7.5	6.5	7.1	5.1	18
20	7.5	7.5	7.5	6.0	6.3	4.7	7.5	7.5	7.5	6.2	6.6	4.8	20
22	7.5	7.5	7.0	5.7	5.8	4.5	7.5	7.5	7.3	5.9	6.1	4.6	22
24	6.8	6.9	6.5	5.4	5.4	4.2	6.7	6.8	6.8	5.6	5.7	4.3	24
26	6.0	6.1	6.1	5.2	5.1	4.0	5.9	6.0	6.1	5.4	5.3	4.1	26
28	5.4	5.5	5.5	5.0	4.7	3.8	5.3	5.4	5.5	5.1	5.0	3.9	28
30	4.9	4.9	5.0	4.8	4.5	3.7	4.8	4.9	5.0	5.0	4.7	3.8	30
32			4.6	4.6	4.2	3.5	4.3	4.3	4.5	4.6	4.5	3.6	32
34			4.1	4.1	4.0	3.4			4.0	4.1	4.1	3.5	34
36					3.8	3.3			3.7	3.7	3.7	3.4	36
38					3.5	3.2				3.4	3.4	3.3	38
40						3.2					3.1	3.2	40

Load Chart of FJ Configuration

	Load chart -FJ 2/4												
	Во	om 24m~	45m, Jib 9	9m~18m,	Rear cour	iterweight	24.3t, Ca	rbody cou	Interweigl	nt 4t, witho	out main h	nook	
R(m) BL (m)			2	24					BL (m) R(m)				
Jib length(m)		9	13	3.5	1	8		9	1	3.5	1	8	Jib length(m)
Boom to jib angle	15°	30°	15°	30°	15°	30°	15°	30°	15°	30°	15°	30°	Boom to jib angle
10													10
12	7.5						7.5						12
14	7.5	7.5	7.5		7.5		7.5	7.5	7.5				14
16	7.5	7.5	7.5	7.1	7.5		7.5	7.5	7.5	7.2	7.5		16
18	7.5	7.5	7.5	6.7	7.4	5.2	7.5	7.5	7.5	6.8	7.5		18
20	7.5	7.5	7.5	6.3	6.8	4.9	7.5	7.5	7.5	6.5	7.0	5.0	20
22	7.4	7.5	7.5	6.0	6.3	4.7	7.3	7.5	7.5	6.2	6.6	4.8	22
24	6.6	6.7	6.7	5.8	5.9	4.4	6.5	6.6	6.6	5.9	6.1	4.5	24
26	5.8	5.9	5.9	5.5	5.5	4.2	5.7	5.8	5.8	5.7	5.8	4.3	26
28	5.2	5.3	5.3	5.3	5.2	4.0	5.1	5.2	5.2	5.4	5.3	4.2	28
30	4.7	4.8	4.8	4.9	4.9	3.9	4.6	4.7	4.7	4.9	4.8	4.0	30
32	4.1	4.2	4.3	4.5	4.3	3.7	4.0	4.1	4.2	4.3	4.2	3.8	32
34	3.7	3.8	3.9	4.0	3.9	3.6	3.6	3.7	3.8	3.9	3.8	3.7	34
36		3.4	3.5	3.6	3.6	3.5	3.3	3.3	3.4	3.5	3.5	3.6	36
38			3.2	3.3	3.3	3.4	2.9	3.0	3.1	3.2	3.2	3.3	38
40			2.9	2.9	3.0	3.1			2.8	2.9	2.9	3.0	40
44					2.4	2.4					2.3	2.3	44

Combination of Working Conditions

Load Chart of FJ Configuration

	Load chart -FJ 3/4													
	Во	om 24m∼4	45m, Jib 9	⁹ m~18m, I	Rear coun	terweight	24.3t, Ca	rbody cou	nterweigł	nt 4t, witho	out main h	ook		
R(m) BL (m)			3	6					BL (m) R(m)					
Jib length(m)	ç	9	13	8.5	1	8	ç	7	13	3.5	1	8	Jib length(m)	
Boom to jib angle	15	30	15	30	15	30	15	30	15	30	15	30	Boom to jib angle	
12	7.5						7.5						12	
14	7.5	7.5	7.5				7.5	7.5	7.5				14	
16	7.5	7.5	7.5		7.5		7.5	7.5	7.5		7.5		16	
18	7.5	7.5	7.5	6.9	7.5		7.5	7.5	7.5	7.1	7.5		18	
20	7.5	7.5	7.5	6.6	7.3	5.1	7.5	7.5	7.5	6.7	7.5	5.2	20	
22	7.2	7.4	7.4	6.3	6.8	4.9	7.1	7.3	7.3	6.4	7.0	4.9	22	
24	6.4	6.5	6.5	6.0	6.3	4.6	6.3	6.5	6.4	6.2	6.5	4.7	24	
26	5.6	5.7	5.7	5.8	5.8	4.4	5.5	5.6	5.6	5.9	5.7	4.5	26	
28	5.0	5.1	5.1	5.3	5.2	4.2	4.9	5.0	5.0	5.2	5.1	4.3	28	
30	4.5	4.6	4.6	4.8	4.7	4.1	4.3	4.5	4.5	4.7	4.6	4.2	30	
32	3.9	4.0	4.1	4.2	4.1	3.9	3.9	4.0	4.0	4.1	4.1	4.0	32	
34	3.5	3.6	3.7	3.8	3.7	3.8	3.4	3.5	3.6	3.7	3.7	3.9	34	
36	3.2	3.2	3.3	3.4	3.4	3.6	3.1	3.2	3.2	3.4	3.3	3.5	36	
38	2.8	2.9	3.0	3.1	3.1	3.2	2.7	2.8	2.9	3.0	3.0	3.2	38	
40	2.4	2.5	2.7	2.8	2.8	2.9	2.4	2.4	2.5	2.7	2.7	2.8	40	
44			2.1	2.1	2.2	2.3		1.9	2.0	2.0	2.1	2.2	44	
48					1.7	1.8			1.5	1.6	1.6	1.7	48	
52											1.2	1.3	52	

Load Chart of FJ Configuration

	Load chart -FJ 4/4												
Boom 24m~45m, Jib 9m~18m, Rear counterweight 24.3t, Carbody counterweight 4t, without main hook													
R(m) BL (m)			4	2					4	5			BL (m) R(m)
Jib length(m)	(9	13	8.5	1	18		9		3.5	18		Jib length(m)
Boom to jib angle	15	30	15	30	15	30	15	30	15	30	15	30	Boom to jib angle
14	7.5						7.5						14
16	7.5	7.5	7.5				7.5	7.5	7.5				16
18	7.5	7.5	7.5	7.2	7.5		7.5	7.5	7.5	7.2	7.5		18
20	7.5	7.5	7.5	6.8	7.3		7.5	7.5	7.5	6.9	7.1		20
22	7.0	7.2	7.2	6.5	6.8	5.0	6.9	7.1	7.1	6.6	6.6	5.1	22
24	6.1	6.4	6.3	6.3	6.3	4.8	6.0	6.3	6.1	6.2	6.1	4.9	24
26	5.4	5.6	5.5	5.8	5.6	4.6	5.3	5.5	5.4	5.7	5.5	4.7	26
28	4.8	4.9	4.9	5.2	5.0	4.4	4.7	4.9	4.8	5.1	4.9	4.5	28
30	4.2	4.3	4.3	4.6	4.5	4.3	4.1	4.2	4.2	4.5	4.3	4.3	30
32	3.7	3.9	3.9	4.0	4.0	4.1	3.6	3.8	3.8	4.0	3.9	4.0	32
34	3.3	3.4	3.5	3.6	3.6	3.8	3.2	3.3	3.4	3.5	3.5	3.7	34
36	3.0	3.1	3.1	3.3	3.2	3.4	2.8	3.0	3.0	3.2	3.1	3.3	36
38	2.5	2.7	2.8	2.9	2.9	3.1	2.4	2.5	2.7	2.8	2.8	3.0	38
40	2.2	2.3	2.4	2.5	2.5	2.8	2.1	2.2	2.3	2.4	2.4	2.7	40
44	1.7	1.8	1.9	1.9	1.9	2.1	1.6	1.7	1.7	1.8	1.8	2.0	44
48			1.4	1.5	1.5	1.6	1.2	1.2	1.3	1.4	1.4	1.5	48
52					1.1	1.2			0.8	1.0	1.0	1.1	52

Note:

1 . The rated load in the load chart is calculated complying with $\,$ GB/T 3811.

②. The actual rated capacity is the value after deducting the weight of lifting tools (such as lifting hook and steel ropes round the hooks and the boom top),

from the rated load in the load charts.

③. The rated capacity in the load charts is calculated when the crane is parking on firm and level ground and lifting the load slowly and steadily.

4 . See Operation Manual for load charts of FJm and FJa configurations.



Zhejiang Sany Equipment Co.,LTD

SANY Crawler Crane Industrial Park, No. 2188 Daishan Road, Wuxing District, Huzhou City, Zhejiang Province, P. R. China Zip 313028 Consulting sanycrane@sanygroup.com (Crane BU) / crd@sany.com.cn (IHQ) After-sales Service 0086-400 6098 318

Reminder:

Any change in the technical parameters and configuration due to product modification or upgrade may occur without prior notice. The machine in the picture may include additional equipment. This brochure is for reference only, and goods in kind shall prevail. Copyright at SANY. No part of this brochure may be copied or used for any purpose without written approval from SANY.

© Edited in December 2022



